

# Modern Peripheral Vascular Intervention Guidance

PHYSIOLOGY	DIAGNOSTIC	PRE-PVI	POST-PVI
	<ul style="list-style-type: none"><li>▶ Ischemic Burden</li><li>▶ Flow Limitation</li></ul>		<ul style="list-style-type: none"><li>▶ Flow Limitation</li></ul>
IV IMAGING	<ul style="list-style-type: none"><li>▶ Lesion Morphology<ul style="list-style-type: none"><li>▷ Ca<sup>2+</sup></li><li>▷ Lipid</li><li>▷ Thrombus</li></ul></li></ul>	<ul style="list-style-type: none"><li>▶ Device Selection</li><li>▶ Device Sizing<ul style="list-style-type: none"><li>▷ Serial lesion</li><li>▷ Landing zone</li></ul></li></ul>	<ul style="list-style-type: none"><li>▶ Safety<ul style="list-style-type: none"><li>▷ Luminal gain</li><li>▷ Malapposition</li><li>▷ Vessel expansion</li><li>▷ Edge dissection</li><li>▷ Tissue prolapse</li></ul></li><li>▶ Tailoring Final Result</li></ul>

Courtesy of Sahil Parikh, MD

For more, visit [ThePVDChannel.com](http://ThePVDChannel.com)



THE  
PVD CHANNEL